


SHAD

CF MOTO MT 800 '21- TOP MASTER COMT81ST

BCN




1 263085 x 1



2 260900 x 2
Ø16 Ø9 x 36



3 303045 x 2
Ø8



4 304228 x 2
M8 x 100 DIN 7380



5 260523 x 2
Ø16 Ø9 x 25



6 303025 x 2
Ø10



7 304032 x 2
M8x50 DIN 7991

WARNING!

GB Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

